



A FRAMEALL™ DRYWALL GRID SOLUTION

### SHORRIDOR FRAMING SHORLD SHORL

Armstrong®
World Industries

## 

### ShortSpan Framing System

### **CODE COMPLIANCE YOU CAN TRUST**

**FASTER. EASIER. BETTER.** 

ShortSpan® room and corridor framing system, a member of the FrameAll

Drywall Grid Family of Solutions, is the

fastest way to frame drywall ceilings up to 14' wide, while also eliminating

hanger wires/drops for spans up to

The ShortSpan system is designed

9'-0" (cross tees every 16" O.C.).

and manufactured to meet or exceed ASTM standards and code

requirements. This engineered

corridor system helps installers get on and off the job faster,

ShortSpan framing is an effective and productive solution for use in corridors, small rooms, closets,

easier, and better.

restrooms and more.

### Meets:

- ASTM C645
- ASTM C840
- ASTM C754
- ASTM E3090
- ICC Evaluation Report Number ESR-1289
- Department of State Architect - DSA IR 25-3
- AISI A220
- Consult local codes for specific requirements

### **PERFORMANCE**

- PeakForm profile, eliminates hanger wires at span of 8'0" @ 24" OC at 9' 0" @ 16" O.C.
- ScrewStop™ reverse hem prevents screw spin off
- Select items available in High Recycled Content (HRC): 61% Total Recycled Content, 53% Post Consumer Content, 8% Pre-Consumer Content
- Non-HRC items have 30% recycled content
- Components meet broad range of UL® design assemblies (ShortSpan® Tee, LAM, SB12)
- G40, 0.018" metal thickness meets ASTM C645 and AISI A220
- G90 hot-dipped galvanized coating available for interior high-moisture area

- Rotary stitching on double web adds strength and stability

**TABLE OF CONTENTS** 

2-3 Code Compliance & Performance

Components & Moldings

5 ShortSpan® Framing System -**Interior Drywall Ceilings** 

6 ShortSpan® Corridor System

ShortSpan® Installation Info

Load & Vertical Supports

Fire Rated ShortSpan®

**Locking Pocket Mains** 

Integrated Solutions

ShortSpan® StrongBack™ Support

**Angle Molding Options** 

- Knurled ridges improve screw grab during installation
- Beaded bulb adds strength and load capacity

3

### SHORTSPAN® FRAMING SYSTEM -INTERIOR DRYWALL CEILINGS

### THE BEST CHOICE FOR FRAMING CORRIDORS

### **SHORTSPAN® ITEM DETAILS**

### SHORTSPAN® ITEM DATA

ı	tem Number	Length/Item Description	Face Dimension	Profile Height	Simple Span Uniform Load at L/240 (LBS/LF)	Fire Resistive	
;	S7708P S7708PHRC S7708PG90	8' ShortSpan® Tee	1-1/2"	1-13/16"	All items		
;	S7710P S7710PHRC S7710PG90	10' ShortSpan Tee	1-1/2"	1-13/16"	5' Span – 19.1		
;	S7712P S7712PHRC S7712PG90	12' ShortSpan Tee	1-1/2"	1-13/16"	6' Span – 11.2		
;	S7714P S7714PHRC S7714G90	14' ShortSpan Tee	1-1/2"	1-13/16"	8' Span – 4.0		
Ÿ		Custom Length ShortSpan Made-to-Order 5' - 14' Tee	1-1/2"	1-13/16"	Varies		
;	SLP7704 SLP7705 SLP7706	47-13/16" 59-13/16" 71-13/16" ShortSpan Low Profile		7/8" 7/8" 7/8"	-		
-	_AM12 _AM12G90 _AM12HRC	12' Locking Angle Molding (Locking tabs 8" O.C.) 0.018" Metal Thickness	1-1/4" × 1-1/4"	-	-		1-1/2" 1-1/4"
Ī	_AM151220E	12' Locking Angle Molding (Locking tabs 8" O.C.) 0.028" Metal Thickness	1-1/2" × 1-1/2"	-	-		1-1/2" 1-1/4"
;	SB12P	12' StrongBack™ Support (knockouts 8" O.C.) 0.018" Metal Thickness	-	2"	-		۰۰۵۰۰
(	QSLPM12	12' QuikStix™ Locking Pocket Main (Locking tabs 8" O.C.) 0.018" Metal Thickness	1-1/2"	1-1/2"	Vertical Supports @ 4' O.C. – 21.64 Vertical Supports @ 3' O.C. – 40.60	-	
(	QSUTC	QuikStix Uptight Clip (Pre-drilled screw holes)	1-3/4" wide	1-1/2" × 4-1/2"	-	-	

NOTE: All components are available with G90 hot-dipped galvanized coating. Just add G90 suffix to end of Item #, Ex: LAM12G90.

Perspective	
Knurled Angle Molding (KAM)	-



	Item No.	Length	Height	Metal Thickness	Pcs/Ctn	LF/Ctn	Profile
g	KAM10	120"	1-1/4"	0.018"	10	100	<b>T p</b>
	KAM12	144"	1-1/4"	0.018"	10	120	
	KAM12G90	144"	1-1/4"	0.018"	10	120	1-1/4" ) 1-1/2"
	KAM1510	120"	1-1/2"	0.018"	10	100	2"
	KAM1512	144"	1-1/2"	0.018"	10	120	
	KAM151020E	120"	1-1/2"	0.028"	10	100	<b>←</b> 1-1/4", 1-1/2", 2" <del>→</del>
	KAM151220E	144"	1-1/2"	0.028"	10	120	
	KAM151020	120"	1-1/2"	0.033"	10	100	
	KAM1525G90	120"	1-1/2"	0.018"	10	100	
	KAM1520G90	120"	1-1/2"	0.018"	10	100	
	KAM21025	120"	2"	0.018"	10	100	
	KAM21020EQ	120"	2"	0.028"	10	100	
	KAM21020	120"	2"	0.033"	10	100	

Reduce Labor Cost: Eliminates screws, cross tees and hanger wire (in most applications) Reduce Material Cost: Economical price point on components Reduce Waste: Standard and custom lengths - no cartons to throw away System was evaluated using full-scale seismic testing and may be an acceptable solution on your next project. Check with your local code official for approval prior to installations. For official test reports, please contact TechLine at 877 267-7876. Reduce Risk: Up to 2-hour rating with one (1) layer of fire-rated gypsum board. (See pages 8 and 9 for drawing detail.) Resistive when used in applicable UL® fire resistive designs. Fire Guard™ components meet UL Design Listings D501, D502, G523, G524, G526, G527, G528, G529, G531, G553, J502, L502, L508, L513, L515, L525, L526, L529, L564, P501, P506, P507, P508, P509, P510, P513, P514. Fire Rated:

### SHORTSPAN FRAMING TEES ARE ENGINEERED FOR FASTER, EASIER INSTALLATION


- 1-1/2" wide face exceeds the minimum industry standard
- ScrewStop™ reverse hem prevents screw spin-off
- Balanced profile stays flat during installation
- Rotary stitching on double web adds strength and stability
- G40, 0.018" metal thickness meets ASTM C645
- Reduced cleanup and waste at jobsite
- Quick to open
- Cut to length with snips or saw




Beaded bulb adds strength and load capacity



Knurled ridges improve screw grab during installation



Traditional Method to Frame Corridors






ShortSpan Framing and Locking Angle Molding make drywall framing faster and easier



Corridor framing using traditional steel studs






4 5

### TIME SAVING SOLUTION FOR CONGESTED PLENUM INSTALLATIONS

- Eliminates the need for hanger wire
- Reduced labor costs over conventional installation methods in congested plenum
- Alignment crimps at locking tabs for fast, easy alignment



12' Locking Angle Molding (LAM12) -Wall angle molding fabricated from hot-dipped galvanized steel. The molding features locking details at 8" centers that lock and hold the ShortSpan® framing tees.

### Crimped Area (For Easy Application Of Strongback) -Rotary Stitch Waved Surface Screwstop (Prevents Slippage)

ShortSpan Tee (S7708P, S7710P, S7712P, S7714P) -ShortSpan eliminates cross tees, screws, and hanger wire. Rotary stitching on double web adds strength and stability. G40, .018" metal thickness meets ASTM C645.

### LOAD TEST DATA

				U	Hanger niform Load at	Spacing : L/240 (LBS/L	F)		
ShortSpan Tees	Web Height	36"	48"	60"	72"	84"	96"	102"	108"
S77**P	1-13/16"	-	36.7	19.1	11.2	7.2	4.8	4.0	3.3
QuikStix™ Locking Pocket Main									
QSLPM12	1-1/2"	40.60	20.87	-	-	-	-	-	-
StrongBack™ Support Hanger			Hai	nger Spacing l	Jniform Load a	t L/360 (LBS/	LF)		
SB12P	2"	27.53	17.76	-	-	-	-	-	-

### MAXIMUM ALLOWABLE LOAD, LBS./SF@L/240 DEFLECTION


								(Spa	ans over 9' red	quire StrongB	ack)
Item Number	O.C. Spacing	48" Span LBS/SF	60" Span LBS/SF	72" Span LBS/SF	84" Span LBS/SF	96" Span LBS/SF	102" Span LBS/SF	108" Span LBS/SF	120" Span LBS/SF	144" Span LBS/SF	168" Span LBS/SF
S77**P	8"	-	28.6	16.8	10.8	7.2	6.0	4.9	28.6	16.8	10.8
S77**P	16"	27.5	14.3	8.4	5.4	3.5	3.0	2.4	14.3	8.4	5.4
S77**P	24"	15.88	9.5	5.6	3.6	2.4	2.0	1.6	9.5	5.6	3.6
SLP77**	16"	5.12	2.61	1.52	-	-	-	-	-	-	-
SLP77**	24"	3.41	1.74	-	-	-	-	-	-	-	-

Red numbers are Fire Guard items.

NOTE: 5/8" drywall weighs 2.4 lbs./SF (tees installed 8" or 16" or 24" O.C.) 1/2" drywall weighs 2.0 lbs/SF (tees installed 8" or 16" or 24" 0.C) KAM or LAM angle is required to achieve the listed loads above.

### INTERSECTING CORRIDORS, SHORTSPAN, I-BEAM GIRDER

	Intersecting Corridor Span (B)						
	4'	5'	6'	7'	8'	8' 6"	
I-Beam Span (A)			Allowable L	.oad (lb/ft²)			
6'	5.00+	5.00+	5.00+	5.00+	4.57	4.35	
7'	5.00	4.29	3.75	3.33	3.00	2.86	
7'-6"	4.33	3.71	3.25	2.89	2.60	2.48	
8'	3.82	3.28	2.87	2.55	-	-	
8'-6"	3.00	2.57	-	-	-	-	



NOTE: Use this detail when a wire to structure is not feasible.


### **INSTALLATION & BENEFITS OF ARMSTRONG WALL ANGLE OPTIONS**

Locking Angle Molding (LAM) and Knurled Angle Molding (KAM) for drywall framing has the time-saving advantages of knurling, ScrewStop™, pre-punched holes, and no cartons to throw away.


Knurling:	Helps the screws to grab quickly.
ScrewStop: Reverse hem on the top and bottom flanges catches the screw, preventing it from slipping off the wall angle – no sharp edges on the top or bottom of the angle.	
Pre-punched Holes:	Located every 4" on the top edge to allow for faster insertion of the screws.
No Carton Packaging: Eliminate time needed to open and throw away cartons. Just cut the plastic strap and go.	
Code Performance	Meets ASTM 645 gauge and code options

### **LOCKING ANGLE MOLDING (LAM)**


- Pre-engineered locking tabs punched 8" O.C.:
- Eliminates measuring 16" or 24"
- Locking tabs prevent lateral and upward movement
- Eliminates screws, pop rivets, or crimpers needed to attach tees to molding
- Alignment crimp and locking tabs for fast, easy alignment
- LAM is designed to only work with ShortSpan products




LAM - Locking Angle Molding





- Available in 10-piece bundles in 10' and 12'
- Straighter, stronger, safer runs
- Space your soffit framing 4' O.C. with no overlapping and no scrap
- SimpleCurve® Angle Molding product available for curved conditions






**KNURLED ANGLE MOLDING (KAM)** 






### **SHORTSPAN INSTALLATION**


1 Start by cutting the center of the first locking tab (at the alignment crimp) at the first wall or starting point to obtain 16" spacing.



2 It is necessary to screw the Locking Angle Molding to wall structure (use #8 screw, minimum, and the proper screw type and length needed for the application).




3 ShortSpan tees must be cut within 1/4" of the vertical leg of the Locking Angle Moldings (for non-rated installations only).




5 Insert flange of the tee into the large pocket (A) on the right and side of the LAM then slide back into the opposite flange (B) on the smaller tab until you hear an audible click.


No additional requirements for seismic areas – There is no need to screw ShortSpan tees to LAM in seismic design categories A-F (unless required by local code).



6 StrongBack installation is required when supported spans are greater than 9'. See next page.




4 Align the cut ends of the ShortSpan tees to they are all on one side of the room or corridor. The other end (crimped ends) should be all on one end of the installation – this is for ease of StrongBack™ installation.





### EASIER, PRE-ENGINEERED SOLUTION TO SUPPORT SPANS GREATER THAN 9' - 0"


- Knockouts 8" O.C. eliminates measuring, screwing, and splicing
- Allows vertical supports at 4' O.C. instead of 24" or 16"
- Reduces lateral movement
- Resists upward movement if used with vertical tee post or stud
- Easier to level system compared to traditional framing




### INSTALLATION RECOMMENDATIONS







2 Flattened bulb allows StrongBack to slide over bulb



3 Slide StrongBack into place - no bending of tab required


### ALTERNATIVE METHOD TO INSTALL STRONGBACK™ SUPPORT HANGER



1 Open StrongBack (SB12P) lock tabs with pliers (easier if performed on floor)



2 Slide StrongBack over bulb of ShortSpan tee and engage by bending lock tabs back to original position



3 Support and level system to structure; attach vertical supports to StrongBack as required



4 To provide stability to StrongBack, it is recommended to bend first 4" to 90° and pin to wall

### **FIRE RATED**

11

### **LOAD & VERTICAL SUPPORTS**

### SHORTSPAN® VERTICAL SUPPORT REQUIREMENTS

Tees installed 16" O.C. with 5/8" or 1/2" drywall (Seismic Design Categories A, B, C, D, E, F)

Up to 9'-0" span	No vertical support required
9'-0" to 14'-0" span	Mid-span vertical support required


Tees installed 24" O.C. with 5/8" drywall (Seismic Design Categories A, B, C, D, E, F)


Up to 8'-0" span	No vertical support required
8'-0" to 14'-0" span	Mid-span vertical support required


### SECTION PROPERTIES - ASTMC754 TABLE 3

	Min. Base Metal	Design	Gross Area	Effective Properties		
Section	Thickness (in)	Thickness (in)	(in2)	lxx2 (in4)	Ma (ft-lb)	
ShortSpan®	0.0179	0.018	0.103	0.03915	55.86	
StrongBack™	0.0335	0.034	0.092	0.033	45.6	

### **VERTICAL SUPPORT OPTIONS**









Manufactured StrongBack

Hanger Wire

QuikStix™ Uptight Clip







Scrap Tee Support

Field Assembled Support

### **INSTALLATION RECOMMENDATIONS**

- 1 Vertical supports to structure should be either QuikStix™ Uptight Clips or stiff legs using scrap metal. Wire is NOT recommended for hanging this system.
- 2 ShortSpan tees must be cut within 1/4" of vertical leg of the Locking Angle Moldings and Locking Pocket Mains.
- 3 To engage ShortSpan tees into Locking Pockets: insert right hand flange of tee into long pocket first and allow left flange to clear short pocket; rest flat. Slide tee to the left to engage in short pocket (audible click).






### **INTEGRATED SOLUTIONS**

**SPANS & SUPPORT OPTIONS** 

### **LOAD POCKET MAINS**

- Reduces time and labor installing drywall ceilings in tight plenum conditions
- Uptight clip allows installation in 1-1/2" to 5-1/2" plenums
- Locking Pocket Main has the same characteristics as StrongBack™
- Locking Pocket Main allows uptight installation since it is installed at the same level as the ShortSpan tees
- ShortSpan® Tees can span up to 9'-0" without vertical support (16" O.C.)
- Locking Angle Mold eliminates measuring, marking and screwing at perimeters



Main Beam

O.C. Spacing QSLPM12 - 7' O.C.

QSLPM12 - 7'6" O.C.

QSLPM12 - 8' O.C.


QSLPM12 - 8'6" O.C.

QSLPM12 - 8'6" O.C.

### MAXIMUM LOAD IN LBS/SF (L/240 PER ASTM C645)

Main Beam O.C. Spacing	Vertical Support (Tee Post, Hanger Wire, or QSUTC) Spacing Along Main Beam	Max Load in LBS/SF
QSLPM12 - 4' O.C.	4'	5.22
QSLPM12 - 5' O.C.	4'	4.17
QSLPM12 - 6' O.C.	4'	3.48
QSLPM12 - 7' O.C.	4'	2.98
QSLPM12 - 7'6" O.C.	4'	2.78
QSLPM12 - 8' O.C.	4'	2.61
QSLPM12 - 8'6" O.C.	4'	2.46

	·
OTE: 5/8" drywall weighs 2.4 LBS/SF or	less
1/2" drywall weighs 2.0 LBS/SF or	less
Fixtures should be independently	
*For other combinations; consult T	echLine at 877 276-7876



Max Load

in LBS/SF

6.60

6.16

5.77

5.43

Vertical Support (Tee Post, Hanger Wire,

or QSUTC) Spacing

Along Main Beam


3'

3'


3'

3'


### LAM-12 or KAM-12 ShortSpan Tee -24" O.C. Must Be Securely Attached to Wall



24" O.C. spacing of ShortSpan at max span of 8'-0"




16" O.C. spacing of ShortSpan at max span of 9'-0"



24" O.C. spacing of ShortSpan® showing StrongBack™

16" O.C. spacing of ShortSpan showing StrongBack




16" O.C. staggered, cantilever layout for 17' max span

ShortSpan Intersection Corridors with I-Beam Girder


INTEGRATED SOLUTIONS NOTES

### **TRANSITIONS**


### ShortSpan at Perimeter Wall




### ShortSpan Low Profile at Perimeter Wall




### ShortSpan with StrongBack Splice Application



### ShortSpan at Wall



### Fixture Installation



# NEXT STEPS

### 877 276-7876

Customer Service Representatives 7:45 a.m. to 5:00 p.m. EST Monday through Friday

TechLine – Technical information, detail drawings, CAD design assistance, installation information, other technical services – 8:00 a.m. to 5:30 p.m. EST, Monday through Friday. FAX 800 572-8324 or EMAIL: techline@armstrongceilings.com

### armstrongceilings.com/commercial

Latest product news

Standard and custom product information

Online catalog

CAD, Revit®, SketchUp® files

A Ceiling for Every Space® Visual Selection Tool

Product literature and samples – express service or regular delivery

Contacts - reps, where to buy, who will install



### armstrongceilings.com/savingscalc

The Armstrong Savings Calculators are here to help you save vs. traditional construction methods.

Just plug in your job specific details and receive a complete dashboard with side-by-side comparisons, solution benefits, details, and photos that can be used on your next project or shared with a project resource.

Visit the link above to start saving time and money today!



