



Create A CURRENT

Variations in size, placement, and spacing inspire a flowing linear harmony

- ▶ Add as an accent or a dramatic full room installation
- Wave designs create visual variety depending on spacing and direction
- ► Coordinate with Infusions® Walls, Partitions, Canopies and SoundScapes® Blades and Shapes

Infuse a splash of color

Infusions® Blades – Concepts ▶
Mecklenburg Aquatic Center, Charlotte,
NC; LS3P, Charlotte, NC





 $\qquad \text{Infusions}^{\circledcirc} \ \mathsf{Blades} - \mathsf{Concepts}^{^{\intercal}} \ \mathsf{Arlington} \ \mathsf{Lexus}, \\ \mathsf{Arlington} \ \mathsf{Heights}, \ \mathsf{IL}; \ \mathsf{Lew} \ \mathsf{Neuman}, \ \mathsf{Indianapolis}, \ \mathsf{IL}$

LAY DOWN YOUR GROOVE

Ebb and flow in rhythmic grooves mixing variations in size, placement, and spacing

GIVE AND TAKE


Dramatic interplay with lighting, color, and textures



INFUSIONS® Blades – Concepts

Linear Panels smooth texture





▲ Infusions® Blades – Concepts vertical panels in Refined Lagoon

Playful translucent vertical panels, with unique wave designs, interplay with lighting, colors, and textures.

KEY SELECTION ATTRIBUTES

- · Create a colorful accent area or add dramatic visual impact with a full-room installation
- · Select products included in the FAST134 program - ready to ship in 4 weeks or less
- · Unique wave designs can create a variety of visuals depending on the spacing of the vertical panels and the direction of installation
- Infusions® Blades Concepts translucent panels coordinate with Armstrong® ceiling products and other interior finishes, including Infusions™ Walls, Partitions and Canopies, and SoundScapes® Blades and Shapes

COLORS Due to printing limitations, shade may vary from actual product.

Solids





















Bliss (TBB)





Patterns



Copper (TSC)





Natural Linen (TNL)†



(TNF)

Crystalline Silverado (TSV)



Focus

(TCR)

Latte (TLL)

Surf (TNS)

Renewal (TAR)



Clear Arbor (TCA)


Color may vary panel to panel

Due to the unique nature of the woven fabric used in these products, color may vary from panel to panel.

INFUSIONS® Blades - Concepts

Linear Panels smooth texture

PERFORMANCE SELECTION PANEL SELECTION





FAST134 program items ready to ship from manufacturer in 4 weeks or less. Up-to-date lead times and product options (sizes and colors) at armstrongceilings.com/fast134.

When specifying or ordering, include the appropriate 3-letter color suffix. (Example: 7086 <u>T S H</u>)

† Thickness of panels varies by pattern from 0.245" to 0.298"

Dots represent high level of performance.

SUSPENSION COMPONENTS			
Item Number	Description	Color	Pieces/Carton
7137AB	96" Suspension Bar for Infusions Blades Concepts with connector holes on both ends (hardware included)	Anodized Black	8 bars/4 connectors/8 screws
6651AB	Suspension Bar End-to-End Connectors and Screws	Anodized Black	4 connectors/8 screws
6655	Blades Hanging Kit**	Metal	1 kit – 4 hanging points

^{**} Each Blades Hanging Kit includes four hanging assemblies. Use one kit for each suspension bar.

PHYSICAL DATA

Material Polycarbonate

Surface Finish

Fire Performance

Infusions® Blades – Concepts panels have been tested according to NFPA 286 and are equivalent to Class A Interior Finish as defined by the International Building Code.

Designers and installers are advised to consult a fire protection engineer, NFPA 13, and local codes for guidance where automatic fire detection and suppression systems are present.

Contact TechLine at 1 877 276-7876 for specific U.S. and Canadian fire performance data.

Design Considerations

Infusions Blades – Concepts panels are not approved for exterior application.

Due to the unique nature of the woven fabric used in this product, Natural Linen and Blue Linen colors may vary panel to panel.

The wave design on Infusions® Blades — Concepts panels is a 4' pattern. Six-foot Blades panels should only be pared with 48" or 96" Blades panels. Six-foot Blades panels should not be placed end-to-end when used with 48" and 96" Blades panels. Installation Considerations

Do not allow panel edges to get wet or be exposed to moisture. Any fixtures adjacent to Infusions® Blades – Concepts panels must be independently supported. There is potential for limited natural deflection of panels

Infusions® Blades – Concepts panels can be damaged by exposure to high temperatures. Panel temperature should not be permitted to exceed 100°F.

Spacing between two adjacent Blades panel ends must be a minimum of 1/4".

Seismic Restraint
Infusions Blades — Concepts panels have been engineered, tested, and approved for use in all seismic areas. OSHPD/DSA installations may require additional attachment from panel to suspension bar. Consult Armstrong Ceilings to special order panels to accommodate these applications.

FAST134 Program Considerations Size of Job Matters: Big jobs, over 2500 SF or 50 pieces for shapes/vertical elements will have longer lead times.

Location Matters: Transit time not included. We are ready to ship in 1 week on FAST1 items. However, transit to the states west of Wyoming may add time.

Distributor Truck Schedule Matters: We rely on distribution to help move products around the country. When speed matters, work with your local distributor to ensure FAST134 service.

Stock vs Made-to-Order Matters: FAST3 & FAST4 items are made-to-order and will ship direct to distributor. FAST1 (stocked items) will go through distribution and depend on distributor truck schedules.

Warranty

Details at armstrongceilings.com/warranty

Weight; Pieces/Carton 1.63 lbs/LF 7085, 7086 – 8 pcs/ctn 7087 – 16 pcs/ctn



TAKE THE NEXT STEP

1 877 276 7876

Customer Service Representatives 7:45 a.m. to 5:00 p.m. EST Monday through Friday

TechLine – Technical information, detail drawings, CAD design assistance, installation information, other technical services – 8:00 a.m. to 5:30 p.m. EST, Monday through Friday. FAX 1 800 572 8324 or email: techline@armstrongceilings.com

armstrongceilings.com/commercial

Latest product news

Standard and custom product information

Online catalog

CAD, Revit®, SketchUp® files

A Ceiling for Every $\mathsf{Space}^{\scriptscriptstyle{\circledR}}$ Visual Selection Tool

Product literature and samples – express service or regular delivery

Contacts – reps, where to buy, who will install

YOU INSPIRE™ SOLUTIONS CENTER

email: solutionscenter@armstrongceilings.com armstrongceilings.com/youinspire

Design Assistance

Collaborative design

Detail drawings

Specifications

Planning and budgeting

Pre-construction Assistance

Layout drawings for standard and premium products

Project installation recommendations

Contractor installation assistance



helping to bring your one-of-a-kind ideas to life

Revit® Is a registered trademark of Autodesk, Inc.; SketchUp® is a registered trademark of Trimble Navigation Limited; LEED® is a registered trademark of the U.S. Green Building Council. All other trademarks used herein are the property of AWI Licensing LLC and/or its affiliates © 2022 AWI Licensing LLC Printed in the United States of America

armstrongceilings.com/infusions

On the cover: ►

Infusions® Blades – Concepts™

Mecklenburg Aquatic Center, Charlotte, NC; LS3P, Charlotte, NC

